

fans command

This command is used to display the velocity of the server fans.

Use the **fans** command to display the speed for each of the server fans.

Example:

```
system> fans
fan1 75%
fan2 80%
fan3 90%
system>
```

Parent topic: [Monitor commands](#)

[Give feedback](#)

[Send a link to this topic](#)